




BOSCH



H-CLASS VACUUM RETURN PROCESS

All H-Class Dust Extractors must be prepared and packaged in accordance with the below guidelines. BOSCH will not accept any hazardous extractors that are not prepared in the following manner.

For any questions please get in contact below:

www.bosch-pt.com.au/au/en/

CustomerService.PT@au.bosch.com

PH: 1300 3070 44

STEP 1

Do not return accessories. Such as hoses, suction pipes, bags & filters.



STEP 2

Before returning the dust extractor, remove any disposal bags or safety filter bags.



STEP 3

The housing of the dust extractor must be thoroughly vacuumed and wiped clean with a damp cloth.



STEP 4

Ensure the extractor is closed securely & the intake cap is in place as pictured.



STEP 5

Place vacuum into a new clean 200UM clear bag & apply duct tape to neck of bag.

Complete this step twice. (Double bag)



STEP 6

Once double bagged and securely sealed, place the vacuum into a carton for delivery.



STEP 7

Print out & place dangerous goods label supplied by BOSCH onto carton.



STEP 8

Sign & complete dangerous good declaration.

Once complete please email BOSCH for next steps.



CustomerService.PT@au.bosch.com